

Planning the packing space

The space in a frame, which can be used exclusively for holding insert blocks, is called the packing space. In the RGS-type frames the compression system always occupy 40 mm of each frame. In the RGP-type frames no compression system or stayplates are necessary, therefore the packing space consists of the entire interior area of the frame.

